

LED BULB

View the expanded manual: http://aeotec.com/support



### Aeotec by Aeon Labs LED Bulb.

Make any light a smart light.

LED Bulb brings the connected light bulb to Z-Wave. Offering the perfect shades of cool and warm light, along with 16 million shades of other coloured light, LED Bulb is the modern light bulb as it should be: connected, controllable and perfectly considered.

## Familiarise yourself with your LED Bulb.

Your LED Bulb contains all its technology within its silver and white exterior. It has no external buttons.



ADDED WEIGHT OF THE DEVICE MAY CAUSE INSTABILITY OF A FREE-STANDING PORTABLE LUMINAIRE THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS OR NOT FOR EMERGENCY

SUITABLE FOR USE IN ENCLOSED LUMINAIRES.

## Quick start.

Getting your LED Bulb up and running is as simple as inserting it into a lamp holder and adding it to your existing Z-Wave network You'll need to set your Z-Wave hub to accept new products; to d this, please refer to its user manual.



- Toggle off the wall switch into the OFF position. 2. Remove any existing light bulb and replace it with LED Bulb.
- 3. Set your Z-Wave gateway to accept new products. 4. With LED Bulb in its fitting, wait 2 seconds. Now toggle your wall switch ON, LED Bulb's green LED will blink to indicate that it
- is looking for a Z-Wave network to connect to. 5. After successfully connecting to your network, LED Bulb will illuminate. If a network connection has failed, it will remain without light.

## Using LED Bulb.

With your LED Bulb now a part of your smart home, you'll be able to schedule, configure and control it your Z-Wave gateway. Please refer to the relevant pages of your gateway's user manual for instructions on configuring LED Bulb to your needs.

Please note that the wall switch controlling LED Bulb needs to be left in the on position in order for LED Bulb to function within your Z-Wave network. In the off position, LED Bulb will not be able to draw power and will not be remotely controllable nor be able to serve as a Z-Wave repeater.

# (4) Advanced functions.

Manually changing LED Bulb's colour.

LED Bulb can fill your room with multiple shades of white and an additional 16 million different colours. It's possible to manually select some of these without the use of your Z-Wave gateway. To

. Toggle LED Bulb off, on, off, on in quick succession via its wall switch, LED Bulb has now entered colour cycle mode and will

- cycle through the following colours: warm white, cold white, red, orange, yellow, green, cyan, blue and purple.
- 2. When the colour cycle arrives at the colour you'd like to select, toggle off LED Bulb via the wall switch. The visible colour will be

## Removing LED Bulb from a Z-Wave network.

Your LED Bulb can be removed from your Z-Wave network at any time using your Z-Wave gateway. To set your gateway into removal

- mode, please refer to the respective section of is user manual.
- 1. Set your Z-Wave gateway into device removal mode.

set as vour bulb's default.

- 2. Turn LED Bulb's wall switch on. 3. Toggle LED Bulb's wall switch off, on, off, on, off, on in fast
- LED Bulb should now be removed from your Z-Wave network. To confirm successful removal its colour will change to orange for 2 seconds before changing to white. If removal was unsuccessful, LED Bulb will blink orange for 3 seconds before changing to red for 2 seconds.

Removing LED Bulb from your Z-Wave network will reset LED Bulb to default factory settings.

## Security inclusion.

- . Set your Z-Wave hub into pairing mode.
- 2. Toggle off the wall switch controlling your LED Bulb to turn it off (keep it in the "OFF" state for 2 seconds) and then quickly toggle on the wall switch on, off, on, off, on. The blue LED wil
- blink to indicate the Bulb is entering into secure pairing mode. 3. If LED Bulb has been successfully added to your Z-Waye network, its RGB LED will be solid when you turn LED Bulb on.

## Manual configuration.

You may wish to manually configure LED Bulb via Z-Wave command classes through your gateway. What follows is a list of

## the associated information.

Colour Display Cycle Configuration. Parameter 37 [4 byte] will cycle the colour displayed by LED Bulb.

into different mo		····· oyo.		00.00	аора	.you .	,,	
	7	6	5	4	3	2	1	0

		7	6	5	4	3	2	1	0
V	alue 2		Cycle Count						
V	alue 3	Colour Change Speed							
Valu	e 4 (LSB)	Colour Residence Time							

## Colour Display Mode (4 bits)

The Colour Display Cycle field can have the following values corresponding to 4 different modes:

Colour Display Cycle	Description
0	Single Colour Mode.
1	Rainbow Mode(red, orange, yellow, green, cyan, blu violet, pinkish).
2	Multi Colour Mode(colours cycle between selecte colours).
3	Random Mode.
15	Inactive (keep the current configuration values).
4 to 14	Reserved.

## Colour Transition Style (2 bits)

The following values correspond to 3 different transition styles

Transition tyle	Description
0	Smooth Colour Transition.
1	Fast/Direct Colour Transition.
2	Pulsating Dimming.
3	Inactive (keep the current configuration values).

Cycle Count (8 bits) The Cycle Count is used to define the number of repetitions/ cycles displayed by your LED Bulb in Colour Display Cycle before stopping.

Cycle Count	Description
0	Unlimited.
1 to 254	Total number of repetitions/cycles before stopping.
255	Inactive (keep the current configuration values).

Colour Change Speed (8 bits)

This field specifies the transition speed when one colour changes to another.

ed	Description
254	0 is the slowest and 254 is the fastest.
5	Inactive (keep the current configuration values).

### Colour Residence Time (8 bits)

This field specifies the length of time each individual colour is displayed before a transition.

Colour dence Time	Description
to 254	Corresponds from 0 to 25.4 seconds.
255	Inactive (keep the current configuration values).

The table above shows a decimal representation of the settings that can be set on parameter 37.

Parameter 38 [4 byte] can be used to set up to 8 colours to cycle between when LED Bulb is in Multi Colour Mode. Colours transition from Colour Index 1-8.

	7	6	5	4	3	2	1		
Value 1 (MSB)	Colour Index 8				Colour Index 7				
Value 2	(	Colour Index 5							
Value 3	Colour Index 4				Colour Index 3				
Value 4 (LSB)	(	Colour Inc	Colour Index 1			Ī			

## Colour Component Id:

ID	1	2	3	4	5	6	7	8
Colour	Red	Orange	Yellow	Green	Cyan	Blue	Violet	Pinki

If you set the parameter 38 to 801(0x00000321 in hexadecimal), the colour will be changed from Red to Orange and then Orange to Yellow circularly (Red→Orange→Yellow→Red).

## Technical specifications.

Model number: ZW098. Bulb holder type: E26 for USA version, E27 for EU/AU version. Max operating power: 9W.

Max brightness: 850 lumens.

Rated colour temperature: 4700K.

Useful life: 50000 hours. Operating temperature: 0°C to 40°C/32°F to 104°F.

Relative humidity: 8% to 80%. Operating distance: Up to 492 feet/150 meters outdoors.

Version	Input (Standby Power)	Working band
AU	230V 50Hz, Max: 0.7W	921.42MHz
BR	220V 60Hz, Max: 0.7W	921.42MHz
CN	220V 50Hz, Max: 0.7W	868.40MHz
EU	230V 50Hz, Max: 0.7W	868.42MHz
L	230V 50Hz, Max: 0.7W	916.02MHz
IN	230V 50Hz, Max: 0.7W	865.20MHz
UK	230V 50Hz, Max: 0.7W	868.42MHz
US	120V 60Hz, Max: 0.5W	908.42MHz

(7) Warranty.

Aeon Labs warrants to the original purchaser of Products that for the Warranty Period (as defined below), the Products will be free from material defects in materials and workmanship. The foregoing warranty is subject to the proper installation, operation and maintenance of the Products in accordance with installation instructions and the operating manual supplied to Customer Warranty claims must be made by Customer in writing within thirty (30) days of the manifestation of a problem. Aeon Labs' sole obligation under the foregoing warranty is, at Aeon Labs' option, to repair, replace or correct any such defect that was present at the time of delivery, or to remove the Products and to refund the purchase price to Customer.

The "Warranty Period" begins on the date the Products is delivered and continues for 3 years.

Any repairs under this warranty must be conducted by an authorized Aeon Labs service representative and under Aeon Labs' RMA policy. Any repairs conducted by unauthorized persons

shall void this warranty. Excluded from the warranty are problems due to accidents, acts of God, civil or military authority, civil disturbance, war, strikes, fires, other catastrophes, misuse, misapplication, storage damage, negligence, electrical power problems, or modification to the Products or its components.

Aeon Labs does not authorize any person or party to assume or create for it any other obligation or liability in connection with the Products except as set forth herein.

Aeon Labs will pass on to Customer all manufacturers' Material warranties to the extent that they are transferable, but will not independently warrant any Material. Customer must prepay shipping and transportation charges for

returned Products, and insure the shipment or accept the risk of loss or damage during such shipment and transportation. Aeon Labs will ship the repaired or replacement products to Customer freight prepaid.

Customer shall indemnify, defend, and hold Aeon Labs and Aeon Labs' affiliates, shareholders, directors, officers, employees, contractors, agents and other representatives harmless from all demands, claims, actions, causes of action, proceedings, suits, assessments, losses, damages, liabilities, settlements, judgments,

fines, penalties, interest, costs and expenses (including fees and disbursements of counsel) of every kind (i) based upon personal injury or death or injury to property to the extent any of the foregoing is proximately caused either by a defective product (including strict liability in tort) or by the negligent or willful acts or omissions of Customer or its officers, employees, subcontractors or agents, and/or (ii) arising from or relating to any actual or alleged infringement or misappropriation of any patent, trademark, mask work, copyright, trade secret or any actual or alleged violation of any other intellectual property rights arising from or in connection with the products, except to the extent that such infringement

exists as a result of Aeon Labs' manufacturing processes.

IN NO EVENT SHALL AEON LABS BE LIABLE FOR ANY INDIRECT,

INCIDENTAL, PUNITIVE, SPECIAL OR CONSEQUENTIAL DAMAGES,

IN CONTRACT, OR TORT, OR OTHERWISE EVEN IF ADVISED OF

LIABILITY, BREACH OF WARRANTY, BREACH OF AGREEMENT, OF

OR DAMAGES FOR LOSS OF PROFITS, REVENUE, OR USE INCURRED BY CUSTOMER OR ANY THIRD PARTY, WHETHER IN AN ACTION NOT IMMERSE IN WATER. NOT FOR USE WHERE DIRECTLY EXPOSED TO THE POSSIBILITY OF SUCH DAMAGES. AFON LARS' LIABILITY AND CLISTOMER'S EXCLUSIVE REMEDY FOR ANY CAUSE OF ACTION. ARISING IN CONNECTION WITH THIS AGREEMENT OR THE SALE OR USE OF THE PRODUCTS, WHETHER BASED ON NEGLIGENCE, STRICT subject to the following two conditions: EQUITABLE PRINCIPLES, IS EXPRESSLY LIMITED TO, AT AEON LABS' 1 This device may not cause harmful interference, and

2 This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

Reorient or relocate the receiving antenna.

from that to which the receiver is connected.

the following measures:

help.

encouraged to try to correct the interference by one or more of

Increase the separation between the equipment and receive

Connect the equipment into an outlet on a circuit different

Consult the dealer or an experienced radio/TV technician for

FCC NOTICE (for USA) THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT, SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY

TO OPERATE THE EQUIPMENT. STORE INDOORS WHEN NOT IN USE, SUITABLE FOR DRY LOCATIONS, DO

OPTION, REPLACEMENT OF, OR REPAYMENT OF THE PURCHASE

PRICE FOR THAT PORTION OF PRODUCTS WITH RESPECT TO WHICH

DAMAGES ARE CLAIMED. ALL CLAIMS OF ANY KIND ARISING IN

CONNECTION WITH THIS AGREEMENT OR THE SALE OR USE OF

PRODUCTS SHALL BE DEEMED WAIVED UNLESS MADE IN WRITING

WITHIN THIRTY (30) DAYS FROM AFON LABS'S DELIVERY, OR THE

THE INDEMNITY AND WARRANTY IN ABOVE ARE EXCLUSIVE AND

IN LIFU OF ALL OTHER INDEMNITIES OR WARRANTIES, WHETHER

EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

DATE FIXED FOR DELIVERY IN THE EVENT OF NONDELIVERY.

This device complies with Part 15 of the FCC Rules, Operation is

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available.

### Certifications (regional):























FCC ID: XBAFT098


CONFORMS TO UL STD.1993

CERTIFIED TO CSA STD, C22, 2 NO. 1993-09





Z-Wave and Z-Wave Plus are registered trademarks of Sigma Designs and its subsidiaries in the United States







Version:501009800002-AA www.aeotec.com